



Please ensure that all installation procedures are followed strictly according to the provided instructions. Any deviation from the recommended procedures may result in improper installation and could lead to safety hazards or product failure. By proceeding with the installation, you acknowledge that you have been trained in the proper use and installation of the product and accept full responsibility for any consequences arising from the installation process. Additionally, it is your responsibility to wear the proper personal protective equipment (PPE) requirements. Prevent Roofing Solutions makes no representation regarding the adequacy of ventilation design. Published ventilation ratings of ridge vents and soffit systems remain the responsibility of the vent manufacturer and the installer. Compliance with local building codes and manufacturer requirements is the sole responsibility of the installer.

1. Preparation:

- Ensure that all roofing underlayment is installed according to the manufacturer's recommendations and local building codes prior to the installation of Attic Armor.

2. Installation:

- Roll out Attic Armor with the logo facing the sky. This will require two or more installers for safe handling and proper installation.

3. Proper Placement:

- Center the 4" mesh opening of the roll directly over the ridge board (or, if engineered trusses are used, over the ventilation opening). Ensure this is done according to the manufacturer's instructions for maximum effectiveness.

4. Securing the Product:

- Smooth the nailer flange neatly and use staples or roofing nails on each side of the roofline to secure it. Always check with local building codes to verify that the fasteners used are compliant.

5. Installation by Two Installers:

- It is recommended that one installer rolls out the material while the second secures the attachment flange with staples or nails. Always prioritize safety during installation.

6. Handling Joints:

- If the roll runs out before the ventilation opening is completely covered, overlap the new roll by 4" over the existing roll to ensure a seamless installation.



Asegúrese de seguir estrictamente todos los procedimientos de instalación según las instrucciones proporcionadas. Cualquier desviación de los procedimientos recomendados puede resultar en una instalación incorrecta y provocar riesgos de seguridad o fallos del producto. Al proceder con la instalación, usted reconoce haber recibido capacitación sobre el uso e instalación correctos del producto y acepta toda la responsabilidad por cualquier consecuencia derivada del proceso de instalación. Además, es su responsabilidad usar el equipo de protección personal (EPP) adecuado. Prevent Roofing Solutions no se hace responsable de la idoneidad del diseño de ventilación. Las clasificaciones de ventilación publicadas de respiraderos de cumbrera y sistemas de plafones siguen siendo responsabilidad del fabricante del respiradero y del instalador. El cumplimiento de los códigos de construcción locales y los requisitos del fabricante es responsabilidad exclusiva del instalador.

1. Preparación:

- Asegúrese de que toda la base del techo esté instalada de acuerdo con las recomendaciones del fabricante y los códigos de construcción locales antes de instalar Attic Armor.

2. Instalación:

- Extienda Attic Armor con el logotipo hacia el cielo. Se requerirán dos o más instaladores para una manipulación segura y una instalación correcta.

3. Colocación correcta:

- Centre la abertura de malla de 10 cm del rollo directamente sobre la cumbrera (o, si se utilizan cerchas de ingeniería, sobre la abertura de ventilación). Asegúrese de hacerlo según las instrucciones del fabricante para obtener la máxima eficacia.

4. Fijación del producto:

- Alise la brida de la clavadora cuidadosamente y utilice grapas o clavos para techos a cada lado de la línea del techo para fijarla. Siempre consulte los códigos de construcción locales para verificar que los sujetadores utilizados cumplan con las normas.

5. Instalación por dos instaladores:

- Se recomienda que un instalador extienda el material mientras el segundo fija la brida de fijación con grapas o clavos. Priorice siempre la seguridad durante la instalación.

6. Manipulación de juntas:

- Si el rollo se agota antes de que la abertura de ventilación esté completamente cubierta, superponga el nuevo rollo 10 cm sobre el rollo existente para asegurar una instalación sin problemas.